

POWRNET™



Rebounders

(Patent Applied For)

Assembly Instructions

1. Join two poles using 12" **Sleeve** to form first **Vertical Post**
2. Thread tubing through net's **Side Straps**.
3. Insert the top of the tube into net's **black top "cap"**.
4. Insert **H-prong** base into Vertical Post at bottom of post
5. Loop net's **bottom strap's bungee** section onto H-prong's short, **extended leg**
6. Anchor first Vertical Post - step down on H-prong's extended section
7. Position and anchor first Vertical Post's yellow **GuyCords** using **9 in. Yellow Pegs**.
8. Hammer the two pegs into ground as deep as possible
9. Repeat steps 1-5 on other end of net and with **second Vertical Post**
10. BEFORE anchoring second Vertical Post:
11. Pull second Post as far away (apart) from first Post as possible
12. Anchor & secure second post, as in steps 6, 7, & 8 above
13. Assess net's tightness. If desired, make more taut by increasing relative distance between the two vertical posts and/or by tightening guy cords
14. Your PowrNet™ (Patent Pending) is specially equipped with two black, **All-tight washers**. To begin, make sure washers are located as near to the top "cap" as possible. Once H-prongs and pegs have been anchored, squeeze **yellow cords** together, slide washer/s down to further tighten the net. Squeezing yellow cords whenever sliding washer up or down will extend the life expectancy of the All-tight washer.



Warning: This apparatus is intended to serve only as a soccer-ball rebounding goal or target. As with all equipment of this nature, avoid play-action physical contact with this goal and with its components - such contact can cause injury. Continuous adult supervision is necessary when handling and/or using this goal and/or its components. This goal includes parts which pose a danger if handled improperly or in a manner that is inconsistent with their intended use.